

Packing the *SPEED TRACK KIT*

Step 1

Remove all connectors, end spooler, and paper sled.

Place 10 sections "face to face" on their sides in the bottom of the case.



Step 2

Layer the remaining 3 sections flat "face down" on top of the first layer.

In the space between the tracks, lay the paper sled, spooling end, and longer connecting pipes.



Step 3

Insert the connecting pieces into the custom looped belt.

Lay the belt on top of the track sections.

